

QUICK GUIDE

PORTABLE BFT-FM002



Bluefish Technologies Inc.

13940 Bammel N. Houston, Ste 205
Houston, TX 77066

Telephone +1 (713) 482 - 8656

Fax +1 (281) 397 - 6662

eMail support@bftsync.com

Internet www.bftsync.com



Welcome

A cup-holder is recommended for optimum installation.

This quick guide takes you through the initial setup of your EGO CUP. Please refer to your mobile phone operating instruction to familiarize yourself with its Bluetooth functions. Please check the EGO CUP phone supported list (available at www.bftsync.com) to make sure your phone is compatible with the unit prior to installation.

More information and detailed operating instructions can be found on our website at www.bftsync.com.

If you have more questions please visit www.bftsync.com or call our support hotline +1(713) 482 - 8657 (Mon - Fri, 9 AM to 6 PM [CST]).

Contents

- EGO CUP
- Microphone
- Cigarette Lighter Adapter (CLA)
- Cup-holder adapter
- Quick Guide
- Safety information

Connection



CLA jack

Microphone connection

Assembly



Step 3

Insert the EGO CUP assembly into the cup-holder by simultaneously turning clockwise and gently pressing down..

HR system adapter - Assembly

Step 1: Engage HR adapter in HR system (if present in the vehicle)

Step 2

Step 3



Button functions

Accept call, privacy mode, redial



Volume up

Volume down

End call, reject call, enable phone based voice commands

Switching on/off

If your EGO CUP does not power on after connecting to the vehicle's CLA jack you may have to power on the vehicle ignition for use.

If the CLA jack of your vehicle is connected to constant battery power, disconnect the CLA from the CLA jack to protect the life of your battery.




Pairing

- As long as no mobile phone is connected, the EGO CUP is visible for all Bluetooth devices.
- To pair your phone with the EGO CUP just initiate a search for devices from your phone's Bluetooth menu. The device name is "EGO CUP". Select "EGO CUP" from the phone's Bluetooth device list.
- The PIN is "0000".
- After a successful connection/pairing, the LED of the EGO CUP lights up.

LED state with inactive Bluetooth connection

- LED flashes in short intervals  No mobile phone connected

LED states with active Bluetooth connection

- LED permanently on  Mobile phone connected, active network connection
- LED quickly flashes in intervals  Active call
- LED off  No network reception

Bluefish Technologies Inc.

13940 Bammel N. Houston
Suite # 205
Houston, TX 77066

Telephone
Tech. Support
eMail
Internet

+1 (713) 482 - 8656
+1 (713) 482 - 8657
support@bftsync.com
www.bftsync.com

